

SPEED DIAL PROGRAMMING

To program a personal speed dial numbers (100 to 199)

Press # 66 the Display shows “SPEED DIAL”.

Enter Speed Dial number 100 to 199.

Enter Telephone number you want stored then press the # key.

To program a system speed dial numbers (200 to 999)

Press # 66 the Display shows “SPEED DIAL”.

Enter Speed Dial number 200 to 999.

Enter Telephone number you want stored then press the # key.

To use either the personal or the system speed dials

Press a line button

Press the Speed Dial key

Enter the personal or the system speed dial code